

凯越450扭力检查表检查车辆/ Kove 450 Rally Factory Torque inspection

	检查项目 Position		T (N.m)	螺纹胶 Loctit	润滑油 Lube
1	方向柱立管与上连接板	Steering stem tube AND upper connection plate	80		△
2	上连接板与前减震器	Upper connection plate AND front suspension	22		
3	下连接板与前减震器	Lower connection plate AND front suspension	22		
4	下卡座与上连接板	Lower clamp AND upper connection plate	34	=	
5	阻尼器与上连接板	Steering Damper AND upper connection plate	10	=	
6	阻尼器座与车架	Steering Damper mount AND frame	10		
7	前轮轴螺母	Front wheel axle nut	88		
8	前减震器与前轮轴	Front suspension AND front wheel axle	22		
9	前减震器与前刹卡钳	Front suspension AND front brake caliper	32	=	
10	前碟刹盘与前轮毂	Front disc brake AND front wheel hub	12	=	
11	过油螺栓	Oil passage bolt	22		
12	发动机前悬挂与发动机	Engine front suspension AND engine	54		
13	发动机前悬挂与车架	Engine front suspension AND frame	26		
14	发动机上悬挂与发动机	Engine upper suspension AND engine	50		
15	发动机上悬挂与车架	Engine upper suspension AND frame	35	=	
16	发动机下悬挂与车架	Engine lower suspension AND frame	55		
17	发动机后悬挂与车架	Engine rear suspension AND frame	55		
18	平叉轴螺母	Swing arm nut	88		
19	制动臂螺栓	Brake lever bolt	30	=	△
20	后碟刹主泵螺栓	Rear brake cylinder bolt	10		
21	制动踏板螺栓	Brake pedal bolt	5	=	
22	侧支架螺栓	Side stand bolt	5		△
23	侧支架螺母	Side stand nut	22		
24	后减震器上与车架	Rear shock absorber upper AND frame	45		
25	后减震器下与三角摇架	Rear shock absorber lower AND swing arm	45		
26	U型摇架与车架	U-shaped swing arm AND frame	60		
27	链导轮	chain guide wheel	22		
28	U型摇架与三角摇架	U-shaped swing arm AND triangular swing arm	60		
29	平叉与三角摇架	Swing arm AND triangular swing arm	60		
30	后轮轴螺母	Rear wheel axle nut	128		
31	后碟刹盘与后轮毂	Rear brake disc AND rear wheel hub	12	=	
32	换挡臂与换挡轴	Shift arm AND shift shaft	12		
33	消声器前段与发动机	exhaust front section AND engine	22		
34	消声器中段与车架	exhaust middle section AND frame	22		
35	消声器后段与安装支架	exhaust rear section AND mounting bracket	22		
36	油冷器过油螺栓	Oil cooler AND oil plug	25		
37	燃油管与压板连接	Fuel pipe AND fixing plate connection	22		
38	后油箱与车架	Rear fuel tank AND frame	22	=	
39	左右头罩支架与车架	L&R windshield support brackets AND frame	22	=	
40	上下方向轴承	Upper AND lower steering bearings			△
41	后轮油封	Rear wheel oil seal			△

42	平叉轴承	Fork tube bearings			△
43	平叉推力轴承	Fork thrust bearings			△
44	U形摇架轴承	U-shaped swing arm bearings			△
45	三角摇架轴承	Triangular swing arm bearings			△

注：‘=’ 代表需要打螺丝胶， ‘\*’ 代表需要画标识线， ‘△’ 代表需要涂润滑油。

PS：= for locktite, \* for mark line,△ for lubricant

[illegible]
